

Assembly Instructions

PLEASE REFER TO THE DETAILED INSTRUCTIONAL VIDEO AVAILABLE ON OUR WEBSITE,
www.designingfire.com/assembly

TUSCAN TABLE TOP

1. Remove the base from the box.
2. Place a blanket on the ground to protect the surface of the table top.
3. Lay the Tuscan table top face down on the blanket.
4. Take the base and turn it upside down. Line the base up with the 4 pegs and insert the table top into the pegs. (Plastic shavings from the pegs will flake off when frame is inserted into pegs for a tight fit.)
5. Take the table top in one hand and the base in the other and turn it over into an upright position.

GRANITE TABLE TOP

1. Remove the base from the box and the granite table top from the packaging
2. Place the four plastic plugs into the four corners at the top of the base.
3. With the help of another person, set the granite table top on the base so it rests on the four plugs.

The propane tank must be filled before continuing assembly.

TABLE ASSEMBLY

1. Take the propane tank and set it inside the table, resting on the bracket of the base.
2. Make sure your propane tank is lined up with the control valve.
3. Take the regulator and hook it up to the propane tank, making sure the hose forms a U shape and the connection is fastened tightly.
4. Take out your burner and notice the venturi tube underneath the burner. Place the burner into the opening of the table and line up the venturi tube with the control valve.
5. Reach your hand through the opening under the control valve and pull the venturi tube over the end cap of the control valve. **The tube fits loosely on the end cap for safety and oxygen flow.**
6. Open the bags of glass. For design burners, pour the glass into the center for Section A until that is full. Continue to pour glass in Sections B & C until design pattern is complete.
7. To ignite your Oriflamme Fire Table reach underneath, push the control knob in and turn it to the left to the ON position. Propane will begin flowing into the burner.
8. Take your light stick and light it on top. **NEVER light your table from underneath.**

Congratulations. Your Oriflamme Fire Table is now assembled and ready for use.

ADDITIONAL INSTRUCTIONS

To access your propane tank and place additional accessories into you Oriflamme Fire Table you must remove the burner by using the burner puller.

1. First slide your Venturi tube off the end cap. Find the first burner clip which is located above the control valve.
2. Once you have fastened all three burner clips lift the burner off the table top.
3. Place the ice bucket into the Oriflamme Fire Table, pour your ice into the ice bucket to keep your beverages cool.
4. When your Oriflamme Fire Table is not in use, cover the burner and glass with the included protective lid to keep out debris, children, and pets.